

LibraCELL v3.21

- **Start Up**
 - If middle button is pressed during power up, LibraCELL shows "CAL " and adjust the zero offset
 - If menu button is pressed during power up, LibraCELL shows "FACT" and restore cell to factory settings
- **Many other minor fixes!**

LibraPRO v2.21

- **Communications**
 - Improvements in performance when LibraSPLIT is connected
 - Improvements in the LibraCELL discovery protocol
- **Cell brightness**
 - Adjust all the LibraCELL display brightness globally from LibraPRO
- **Relays**
 - Bypass option to hide cells or group of cells from the relay trip engine
- **Many other minor fixes!**

LibraWATCH v4.0.1

- **New design & new graphics**
- **Drag and Drop cells in Stage Plan**
 - o Popup panel appears to the left with all the cells
(Available for desktop and iPad only)
- **Multi Page View** (Available for desktops and iPad only)
 - o Up to 3 screens. Graphic, table and Plan
 - o User can select the size of the screens
 - o Last window and window configuration is automatically saved on LibraWATCH power down
- **Enable/Bypass cells option.**
 - o When a cell or group is bypassed, it won't create a trip in LibraPRO (relays) or LibraWATCH (notification/beep). This function will keep every setting applied to the channel
 - o v2.21 Adds no-cell bypass.
 - o By selecting cells in table view or in the All Views tab and right click you can select to Bypass or to Enable them
 - o Channels bypassed will appear in white
(This function is not saved in power down. The system will be fully Enable after a LibraPRO power cycle)
- **Cell brightness** (Controlled with any LibraWATCH device)
- **Languages**
 - o LibraWATCH is available in more than 10 languages!
 - Russian
 - Portuguese
 - Finnish
 - Turkish
 - Dutch
 - Swedish
 - French
 - German
 - Italian
 - Spanish
 - English
- **Many other minor fixes!**

Support

For support contact Kinesys:

email: support@kinesys.co.uk

web: www.kinesys.co.uk

telephone: +44 (0)20 8481 9850 (0900-1800 Monday-Friday UK time)